

Technical bulletin #7

Touch-up kit instructions

Instructions

1. Clean the damaged surface.
2. Make sure you have the touch-up kit compatible with the color of your floor.
3. Apply the mastic stick to the damaged surface.
4. Fill-in by rubbing on the defect.
5. Gently remove the excess mastic with a plastic scraper.
6. Wipe the surface with a dry cloth.
7. Apply the touch-up marker pen on the damaged surface.
8. Immediately wipe off excess after applying to obtain a better finish.
N.B : This operation consists of removing excess stain around the touched-up area, as it is difficult to remove it when it's dry.
9. Allow to dry for about 30 minutes.
10. Do not apply any cleaning product for the first 24 hours.

Karyne Tremblay, F. Eng
Director of Product development and Quality

Step 1



Step 2 and 3



Step 4



Step 7



Step 8

