

Technical bulletin #10

SolidEdge Product

Installation guide

Stapled, glued or floating installation are allowed for the SolidEdge products. For the instructions, please refer to the Engineered, Herringbone and LOC Installation Guide, available on the MERCIER website.

Nailing is not recommended with this product and may affect the warranty.

Staple caliber	Staple minimum length	Crown	Staple spacing	Distance from board ends
15-16 ga	1 3/4" (44 mm)	1/2" (13 mm)	4" to 6" (102 to 152 mm)	1 1/2" (38 mm)

Caution

It is important to monitor the pressure of the hammer to make sure that the tongues are not damaged

Radiant heating system

It is possible to use the SolidEdge product on a floor equipped with a radiant heating system, but the product should be fixed to the subfloor. Follow the instructions in accordance with the Engineered, Herringbone and LOC Installation Guide.

Applicable warranty

Refer to Mercier 20-years Warranty